



Note
 Prima di iniziare l'operazione, leggere attentamente le avvertenze riportate nel foglio allegato.

Smontaggio componenti originali

Attenzione
 Le operazioni di seguito riportate se non eseguite a regola d'arte possono pregiudicare la sicurezza del pilota.

Note
 Documentazione necessaria per eseguire il montaggio del Kit è il: **Manuale Officina**, relativo al modello di moto in vostro possesso (SC PAUL SMART).

Procedura di Smontaggio

Per lo smontaggio dei fianchetti laterali sinistro (A) e destro procedere come riportato alla **Sez. E 1**.
 Smontare le viti (B) e le bussole (C) da ambo i lati del radiatore olio e recuperare le viti.

Montaggio componenti kit

Importante
 Verificare, prima del montaggio, che tutti i componenti risultino puliti e in perfetto stato.
 Adottare tutte le precauzioni necessarie per evitare di danneggiare qualsiasi parte della moto in cui ci si trova ad operare.

Svitare la vite originale (D), posizionare la staffa (1), avvitare ma non serrare la vite (D).

Prelevare dal kit la staffa (2), posizionarla sul supporto radiatore (lato destro) e avvitare ma non serrare la vite (B) smontata in precedenza.

Prelevare dal kit la staffa (3), posizionarla sul supporto radiatore (lato sinistro) e avvitare ma non serrare la vite (B) smontata in precedenza.

Note
 Read the attached instructions carefully before proceeding.

Removing the original components

Warning
 The following procedure should be carried out as specified. Failure to do so might jeopardize the rider safety.

Note
 Some of the operations required to install this kit are described in the **Workshop Manual** for your motorcycle model (SC PAUL SMART).

Disassembly Procedure

Remove the left (A) and right side body panels as described in **Sect. E 1**.
 Remove screws (B) and bushings (C) on either side of oil cooler and keep the screws.

Kit installation

Caution
 Check that all components are clean and in perfect condition before installation. Adopt any precaution necessary to avoid damages to any part of the motorcycle.

Loosen the original screw (D), set bracket (1); start screw (D) in its thread, but do not tighten yet.

Take bracket (2) from the kit, set it onto radiator mount (right-hand side) and start previously removed screw (B) in its thread, do not tighten yet.

Take bracket (3) from the kit, set it onto radiator mount (left-hand side) and start previously removed screw (B) in its thread, do not tighten yet.